



Code-Signing Tool – HSM

User's Guide

Rev. 3.0.1

May 2018



Revision Sheet

Release No.	Date	Revision Description
Rev. 0	24/05/2018	Initial Work
Rev. 1	27/09/2018	Added support for AHAB and for OpenSSL 1.1.0

USER'S GUIDE

TABLE OF CONTENTS

	<u>Page #</u>
A. Getting started	A-1
1.1 PKCS#11 enabled HSM.....	A-1
1.2 Client/Server based HSM	A-3
B. Installation.....	B-2
2.1 Dependencies.....	B-2
2.2 Get sources	B-3
2.3 Compile sources	B-3
2.3.1 Compile backend.....	B-3
2.3.1 Compile Code-Signing tool.....	B-4
C. Depoly	C-1
3.1 Install HSM	C-1
3.1.1 SoftHSM2	C-1
3.1.2 Utimaco HSM Simulator	C-1
3.3 Create certificates & keys	C-5
3.3.1 Create serial file	C-5
3.3.2 Create passphrase file	C-5
3.3.3 Generate the PKI tree.....	C-6
3.3.4 Generate SRK table	C-6
3.3.4 Command Sequence File (CSF).....	C-7
3.4 Push cryptographic material to HSM.....	C-8
3.4.1 Install p11tool	C-8
3.4.2 Find Token URL.....	C-9
3.4.3 Push certificate & key.....	C-9
3.4.5 Verification	C-12
3.5 Pull certificates from HSM	C-12
3.5.1 Install p11tool	C-12
3.5.1 Find Token URL.....	C-12
3.4.3 Pull Certificates	C-12
3.6 Create HSM configuration file	C-1
D. RUN.....	D-2

1.0 GENERAL INFORMATION

This document provides the information necessary for the user to effectively use Code-Signing Tool with Hardware Security Module backend. It is primarily intended for users who are familiar with CST tool to sign codes for the NXP High Assurance Boot (HAB) and NXP Advanced High Assurance Boot (AHAB).

A. GETTING STARTED

Refereeing to "Appendix B, Replacing the CST Backend Implementation" of Code-Signing Tool User's Guide, NXP has architected the Code-Signing Tool in two parts a Front-End and a Back-End. The Front-End contains all the NXP proprietary operations, while the Back-End containing all standard cryptographic operations. Users can write a replacement for the reference backend to interface with a HSM.

The reference backend uses OpenSSL to perform HAB signature generation and encrypted data generation. OpenSSL in his turn, exposes an Engine API, which makes it possible to plug in alternative implementations for some of the cryptographic operations implemented by OpenSSL. We can take advantage of this to reuse the reference backend with a HSM by offloading cryptographic operations involved during signature generation to HSM.

The engine should re-write an implementation of RSA private encrypt function, ECDSA sign function and how public certificates and private keys are loaded from the HSM to the appropriate data structure X509, RSA, EVP_PKEY and EC_KEY. Optionally SHA digest functions can be re-written also to be performed at the HSM level.

1.1 PKCS#11 enabled HSM

PKCS#11 is a standardized interface for cryptographic tokens which exposes an API called Cryptoki. Cryptographic token manufacturers provide shared libraries (.so or .dll) which implements PKCS#11 standard. Those libraries can be used as bridge between the HSM and the CST Back-End. Typically, the engine loads the shared PKCS#11 module and invoke the appropriate functions on it.

The following figure illustrates the architecture of Code-Signing Tool with a Backend replacement to interface with a PKCS#11 enabled HSM.




Figure 1 HSM-backed CST architecture

The green part of the architecture represents a custom built-in OpenSSL engine which uses PKCS#11 interface to interact with HSM via PKCS#11 implementation library provided by the HSM vendor. It implements all required functions to manage session and tokens, load public certificates, private keys, sign and hash.

Slight modification should be done at the reference backend (blue part) to initialize the engine, perform control command and configuration. In the reference backend public certificates and private keys are loaded from file system. This should be replaced respectively by `ENGINE_load_certificate` and `ENGINE_load_private_key` to load cryptographic material from HSM into appropriate data structures which can be used later. Those functions are bound to low-level functions implemented in the engine.

Below is a non-exhaustive list of well-known smartcards/tokens which support PKCS#11 and the suggested library filename to use.

- aetpkss1.dll (for G&D StarCos and Rainbow iKey 3000)
- cs2_pkcs11.dll (for Utimaco CryptoServer LAN)
- CccSigIT.dll (for IBM MFC)
- pk2priv.dll (for GemSAFE, old version)
- gclib.dll (for GemSAFE, new version)
- dspkcs.dll (for Dallas iButton)
- slbck.dll (for Schlumberger Cryptoflex and Cyberflex Access)

- SetTokI.dll (for SeTec)
- acpkcs.dll (for ActivCard)
- psepkes11.dll (for A-Sign Premium)
- id2cbox.dll (for ID2 PKCS#11)
- smartp11.dll (for SmartTrust PKCS#11)
- pkcs201n.dll (for Utimaco Cryptoki for SafeGuard)
- dkck201.dll (for DataKey and Rainbow iKey 2000 series)
- cryptoki.dll (for Eracom CSA)
- AuCryptoki2-0.dll (for Oberthur AuthentIC)
- eTpkes11.dll (for Aladdin eToken, and some Siemens Card OS cards)
- cknfast.dll (for nCipher nFast or nShield)
- cryst201.dll (for Chrysalis LUNA)
- cryptoki.dll (for IBM 4758)
- softokn3.dll (for the Mozilla or Netscape crypto module)
- iveacryptoki.dll (for Rainbow CryptoSwift HSM)
- sadaptor.dll (for Eutron CryptoIdentity or Algorithmic Research MiniKey)
- pkcs11.dll (for TeleSec)
- siecap11.dll (for Siemens HiPath Scurity Card API)
- asepkcs.dll (for Athena Smartcard System ASE Card)
- /opt/SUNWconn/cryptov2/lib/libvpkcs11.so (for SUN Crypto Accelerator 4000, 32-bit libraries)
- /opt/SUNWconn/cryptov2/lib/sparcv9/libvpkcs11.so (for SUN Crypto Accelerator 4000, 64-bit libraries)
- /opt/SUNWconn/crypto/lib/libpkcs11.so (for SUN Crypto Accelerator 1000, 32-bit libraries)
- /opt/SUNWconn/crypto/lib/sparcv9/libpkcs11.so (for SUN Crypto Accelerator 1000, 64-bit libraries)

1.2 Client/Server based HSM

The HSM-backend is mainly written for PKCS#11 enabled HSMs. In case of Client/Server based HSM the built-in engine can be adapted to implement a client to consume a server exposed API for example. The following requirement should be fulfilled:

- Locate keys/certificates on HSM by an identifier, name or label. This identifier will be kept across cryptographic operation.
- Load partial attributes of private key. In case of RSA should be able to get the value of the modulus and the exponent. It is mandatory to populate RSA structure with those parameters for private keys. OpenSSL uses that for consistency check between certificate and its corresponding private key. In case your HSM is not able to provide partial private keys parameters, you should patch OpenSSL to ignore X509_check_private_key function.
- Write an implementation for RSA init / finish methods and rsa_priv_encrypt method.
- Optionally implement SHA digest methods if you want to perform digesting at HSM level. Methods are: digest_init, digest_update, digest_finish, digest_copy and digest_cleanup
- Engine initialization and destruction.
- In case of stateful service, add a session manager to your implementation.

**2.0 Install
Code-Signing Tool - HSM**

B. INSTALLATION

2.1 Dependencies

The CST-HSM backend depends on:

- OpenSSL library
- Libconfig

Make is required for building the software.

Linux

- 1) Install OpenSSL

```
$ apt-get install openssl libssl-dev
```

libconfig is C/C++ library for processing structured configuration files. It is used by CST to load HSM related configuration.

- 2) Install libconfig

```
$ apt-get install libconfig-dev
```

Windows

Under Windows all setup can be done in top of MSYS2 and MinGW.

- 1) Install MinGW toolchain

For 32-bit:

```
$ pacman -S mingw-w64-i686-gcc make
```

For 64-bit:

```
$ pacman -S mingw-w64-x86_64-gcc make
```

- 2) Install OpenSSL libraries

You can search the repositories by doing:

```
$ pacman -Ss openssl-devel
```

Then install using

```
$ pacman -Ss openssl-devel
```

3) Install libconfig libraries

Search for libconfig-devel and install it by doing:

```
$ pacman -Ss libconfig
```

For 32-bit:

```
$ pacman -S mingw-w64-i686-libconfig
```

For 64-bit:

```
$ pacman -S mingw-w64-x86_64-libconfig
```

2.2 Get sources

The HSM backend source code for CST can be found in the official CST package or checked-out internally from Bitbucket repository.

2.3 Compile sources

To compile backend and CST from source:

2.3.1 Compile backend

1) Verify that the compiler is working by doing:

```
$ gcc -v
```

For Windows open a MSYS2 MinGW 64-bit or a MSYS2 MinGW 32-bit shell.

2) Compile the backend source code using the following command:

From CST package:

```
$ tar xzf cst-release.tgz
$ cd release/code/back_end-hsm/src/
$ make
```

From Bitbucket repository:

```
$ git clone ssh://git@bitbucket.sw.nxp.com/micrse/cst-hsm.git
```

```
$ cd cst-hsm/src
$ make
```

If you have a custom OpenSSL version or installation and you want to compile the backend against it you can use `OPENSSL_PATH` attribute and specifies the path to it.

```
$ make OPENSSL_PATH=/opt/openssl-1.1.0
```

The result is **libbackend.a** static library present in the current working folder.

2.3.1 Compile Code-Signing tool

Taking into consideration the target architecture, copy **libfrontend.a** to current working directory (where **libbackend.a** resides) and then compile CST using the following command:

```
$ cp ../../../../linux64/lib/libfrontend.a .
$ make all
```

The result is **./cst** binary file created in the current working directory .

Optionally, copy or create a symlink to the created cst binary file on linux64/bin folder.

```
$ ln -s ./cst ../../../../linux64/bin/cst-hsm
```

**3.0 DEPLOY
Code-Signing
Tool**

C. DEPOLY

This section provides instructions and prerequisites to deploy Code-Signing Tool with 2 HSMs, these are SoftHSM2 and Utimaco HSM simulator.

3.1 Install HSM

3.1.1 SoftHSM2

Install SoftHSM2

```
$ apt-get install softhsm2
```

Use either softhsm2-util to initialize a token. The SO PIN can e.g. be used to re-initialize the token and the user PIN is handed out to the application so it can interact with the token.

```
$ softhsm2-util --init-token --slot 0 --label "CST-HSM"
```

Type in SO PIN and user PIN.

```
=== SO PIN (4-255 characters) ===
Please enter SO PIN: *****
Please reenter SO PIN: *****
=== User PIN (4-255 characters) ===
Please enter user PIN: *****
Please reenter user PIN: *****
The token has been initialized and is reassigned to slot 66362367
```

Initialized tokens will be reassigned to another slot (based on the token serial number). It is recommended to find and interact with the token by searching for the token label or serial number in the slot list / token info.

3.1.2 Utimaco HSM Simulator

Download and extract SecurityServerEvaluation package.

```
$ cd SecurityServerEvaluation-
V4.20.0.4/Software/Linux/Simulator/sim5_linux/bin
$ ./cs_sim.sh
```

Copy cs_pkcs11_R2.cfg to /etc

```
$ cp /home/nxf45729/SecurityServerEvaluation-V4.20.0.4/Software/Linux/x86-
64/Crypto_APIs/PKCS11_R2/sample/cs_pkcs11_R2.cfg /etc
```

Edit /etc/cs_pkcs11_R2.cfg configuration file and

- Uncomment Logpath = /tmp in [Global] section
- Add Device = [3001@127.0.0.1](#) to [CryptoServer] section
- Save the file

Install java if it is not installed on your system

```
$ apt-get install default-jre
```

Launch p1lcat

```
$ java -jar /home/nxf45729/SecurityServerEvaluation-
V4.20.0.4/Software/Linux/x86-64/Administration/p1lcat.jar
```

From the menu bar click **Login/Logout**

Select a slot from the **Slot List grid**

Select **Login Generic**

Type **ADMIN** as UserName

Select Keyfile as Authentication Token

Click browse button and find the **ADMIN.key** file

The keyfile is under SecurityServerEvaluation-V4.20.0.4/Software/Linux/x86-64/Administration/key/ADMIN.key

Click Login

The screenshot shows the Administration GUI with the following components:

- Menu Bar:** Info, Login/Logout, Slot Management, Object Management, Config Management, Backup/Restore, About.
- Toolbar:** Restart, Info, Login/Logout, Slot Management, Object Management, Config Management, Backup/Restore.
- Slot List Table:**

Slot ID	Token I...	PIN I...	Login St...
0000 0000	✓	✓	
0000 0001			
0000 0002			
0000 0003			
0000 0004			
0000 0005			
0000 0006			
0000 0007			
0000 0008			
0000 0009			
- Login/Logout Configuration Panel:**
 - Tree view: Login SO, Login User, **Login Generic** (selected).
 - User Name: ADMIN
 - Authentication Token: Password Keyfile Smartcard
 - Keyfile: /x86-64/Administration/key/ADMIN.key (with a "Browse" button)
 - Password (optional): [Empty field]
 - Logout All button
- Status Log:**
 - May 28, 2018 3:42:56 PM Slot 0000 0000: SO logged out.
 - May 28, 2018 3:42:56 PM Slot 0000 0000: New authentication state: 00000000.
 - May 28, 2018 3:42:56 PM Slot 0000 0000: Session closed.
- Bottom Bar:** 3001@127.0.0.1 - SLOT_0007

From **Slot Management** menu click

In **Init Token** form define the **Token Label** and **SO PIN** then click **Init Token**

Info Login/Logout Slot Management Object Management Config Management Backup/Restore About

Restart Info Login/Logout Slot Management Object Management Config Management Backup/Restore

Slot List

Slot ID	Token I...	PIN I...	Login St...
0000 0000	✓	✓	
0000 0001			
0000 0002			
0000 0003			
0000 0004			
0000 0005			
0000 0006			
0000 0007			22000...
0000 0008			
0000 0009			

Slot Management

Init Token

Token Label:

SO PIN:

Confirm SO PIN:

▶ Init PIN

▶ Set PIN

▶ Delete SO

Status

- May 28, 2018 3:42:56 PM Slot 0000 0000: SO logged out.
- May 28, 2018 3:42:56 PM Slot 0000 0000: New authentication state: 00000000.
- May 28, 2018 3:42:56 PM Slot 0000 0000: Session closed.
- May 28, 2018 3:44:25 PM Slot 0000 0007: Session opened.
- May 28, 2018 3:44:25 PM Slot 0000 0007: Generic user "ADMIN" logged in.
- May 28, 2018 3:44:25 PM Slot 0000 0007: New authentication state: 22000000.
- May 28, 2018 3:44:44 PM Slot 0000 0007: Token initialized.
- May 28, 2018 3:45:06 PM Slot 0000 0007: SO deleted.

3001@127.0.0.1 - SLOT_0007

From **Login/Logout** menu click **Logout All**
 From **Login/Logout** menu click **Login SO**

Info Login/Logout Slot Management Object Management Config Management Backup/Restore About

Restart Info Login/Logout Slot Management Object Management Config Management Backup/Restore

Slot List

Slot ID	Token I...	PIN I...	Login St...
0000 0000	✓	✓	
0000 0001			
0000 0002			
0000 0003			
0000 0004			
0000 0005			
0000 0006			
0000 0007	✓		
0000 0008			
0000 0009			

Login/Logout

Login SO

SO PIN: Login

Logout All

Login User

Login Generic

Status

- May 28, 2018 3:44:25 PM Slot 0000 0007: Generic user ADMIN logged in.
- May 28, 2018 3:44:25 PM Slot 0000 0007: New authentication state: 22000000.
- May 28, 2018 3:44:44 PM Slot 0000 0007: Token initialized.
- May 28, 2018 3:45:06 PM Slot 0000 0007: SO deleted.
- May 28, 2018 3:46:18 PM Slot 0000 0007: Token initialized.
- May 28, 2018 3:46:32 PM Slot 0000 0007: Generic user logged out.
- May 28, 2018 3:46:32 PM Slot 0000 0007: New authentication state: 00000000.
- May 28, 2018 3:46:32 PM Slot 0000 0007: Session closed.

3001@127.0.0.1 - SLOT_0007

From **Slot Management** menu click **Init PIN**
Set User PIN for example 123456

3.3 Create certificates & keys

Referring to **Key and Certificate Generation HAB Code Signing Tool User's guide**, generate keys and certificates which will be used to sign boot loader image.

If you already have the cryptographic material on the disk, please go directly to *push cryptographic material to HSM* section

3.3.1 Create serial file

serial - 8-digit OpenSSL uses the contents of this file for the certificate serial numbers.

```
$ cd release/keys
```

```
$ echo "28280581" > serial
```

3.3.2 Create passphrase file

key_pass.txt - Contains your pass phrase that will protect the HAB code signing private keys.

```
$ echo "maro1337" > key_pass.txt
$ echo "maro1337" >> key_pass.txt
```

3.3.3 Generate the PKI tree

HABv4

```
$ ./hab4_pki_tree.sh
```

When prompts please answer according to the following:

```
Do you want to use an existing CA key (y/n)?: n
Do you want to use Elliptic Curve Cryptography (y/n)?: n
Enter key length in bits for PKI tree: 2048
Enter PKI tree duration (years): 10
How many Super Root Keys should be generated? 4
Do you want the SRK certificates to have the CA flag set? (y/n)?: y
```

Private keys will generate on keys directory and corresponding Certificates are placed in the crts directory.

AHAB

```
$ ./ahab_pki_tree.sh
```

When prompts please answer according to the following:

```
Do you want to use an existing CA key (y/n)?: n
Do you want to use Elliptic Curve Cryptography (y/n)?: y
Enter length for elliptic curve to be used for PKI tree:
Possible values p256, p384, p521: p384
Enter the digest algorithm to use: sha384
Enter PKI tree duration (years): 10
Do you want the SRK certificates to have the CA flag set? (y/n)?: y
```

3.3.4 Generate SRK table

Create fuse table and binary (SRK table) to be flashed.

HABv4

```
$ cd ../crts
```

```
$ ../linux64/bin/srktool -h 4 -t SRK_1_2_3_4_table.bin -e
SRK_1_2_3_4_fuse.bin -d sha256 -c
./SRK1_sha256_2048_65537_v3_ca_cert.pem,./SRK2_sha256_2048_65537_v3_ca_cert.pem
,./SRK3_sha256_2048_65537_v3_ca_cert.pem,./SRK4_sha256_2048_65537_v3_ca_cert.pe
m -f 1
```

SRK_1_2_3_4_table.bin - SRK table contents with HAB data

SRK_1_2_3_4_fuse.bin - contains SHA256 result to be burned to fuse

AHAB

```
$ cd ../crts
```

```
$ ../linux64/bin/srktool -a -s sha384 -t SRK1234table.bin -e SRK1234fuse.bin
-f 1 -c
SRK1_sha384_secp384r1_v3_ca_cert.pem,SRK2_sha384_secp384r1_v3_ca_cert.pem,SRK3_
sha384_secp384r1_v3_ca_cert.pem,SRK4_sha384_secp384r1_v3_ca_cert.pem
```

3.3.4 Command Sequence File (CSF)

CST tool requires CSF script. This file describes certificates, keys and the data ranges used in sign and encryption functions.

HAB

Create **u-boot.csf** file.

```
$ cd ../linux64/bin/
$ nano u-boot.csf
```

```
[Header]
Version = 4.1
Security Configuration = Open
Hash Algorithm = sha256
Engine Configuration = 0
Certificate Format = X509
Signature Format = CMS
Engine = CAAM

[Install SRK]
File = "../../crts/SRK_1_2_3_4_table.bin"
Source index = 0

[Install CSFK]
File = "../../crts/CSF1_1_sha256_4096_65537_v3_usr_cert.pem"
```

```
[Authenticate CSF]

[Install Key]
# Key slot index used to authenticate the key to be installed
Verification index = 0

# Key to install
Target index = 2
File = "../../crts/IMG1_1_sha256_4096_65537_v3_usr crt.pem"

[Authenticate Data]
Verification index = 2
Blocks = 0x00000000 0 0xd4454 "flash.bin"
```

AHAB

The CSF contains the input files and keys used by CST to create the final image already signed. Please report the offsets noted previously when run mkimage.

```
[Header]
Target = AHAB
Version = 1.0
[Install SRK]
# SRK table generated by srktool
File = "../../crts/SRK1234table.bin"
# Public key certificate in PEM format
Source = "../../crts/SRK1_sha384_secp384r1_v3_ca crt.pem"
# Index of the public key certificate within the SRK table (0 .. 3)
Source index = 0
# Type of SRK set (NXP or OEM)
Source set = OEM
# bitmask of the revoked SRKs
Revocations = 0x0
[Authenticate Data]
# Binary to be signed generated by mkimage
File = "flash.bin"
# Offsets = Container header Signature block (printed out by mkimage)
Offsets   = 0x400           0x590
```

3.4 Push cryptographic material to HSM

3.4.1 Install p11tool

To perform interact with HSM you can use p11tool.

```
$ apt-get install gnutls-bin
```

3.4.2 Find Token URL

You need to locate your HSM vendor's PKCS#11 interface implementation in order to use it with p11tool and CST later.

Utimaco pkcs#11 library is *SecurityServerEvaluation-V4.20.0.4/Software/Linux/x86-64/Crypto_APIs/PKCS11_R2/lib/libcs_pkcs11_R2.so*

SoftHSM2 pkcs11# library is */usr/lib/softhsm/libsofthsm2.so*

Find the Token URL to interact with the token.

```
$ p11tool --provider <pkcs11_lib_path> --list-tokens
```

Example using SoftHSM2

```
$ p11tool --provider /usr/lib/softhsm/libsofthsm2.so --list-tokens
```

```
Token 0:
  URL:
pkcs11:model=SoftHSM%20v2;manufacturer=SoftHSM%20project;serial=9c1aeb00e05a348b;token=CST-HSM
  Label: CST-HSM
  Type: Generic token
  Manufacturer: SoftHSM project
  Model: SoftHSM v2
  Serial: 9c1aeb00e05a348b
  Module: (null)
```

In this case Token URL is

```
pkcs11:model=SoftHSM%20v2;manufacturer=SoftHSM%20project;serial=9c1aeb00e05a348b;token=CST-HSM
```

3.4.3 Push certificate & key

To match a certificate to a private key, both should have the same ID, for some other HSM implementations they should have the same label.

HAB

- 1) Push CSF certificate and private key

Utimaco HSM Simulator

Private Key

```
$ p11tool --provider /home/nxf45729/SecurityServerEvaluation-  
V4.20.0.4/Software/Linux/x86-64/Crypto_APIs/PKCS11_R2/lib/libcs_pkcs11_R2.so  
"pkcs11:model=CryptoServer;manufacturer=Utlimaco%20IS%20GmbH;serial=UTIMACO%20  
CS000000;token=CryptoServer%20PKCS11%20Token" so --login --write --load-  
privkey ../../keys/CSF1_1_sha256_2048_65537_v3_usr_key.pem --label  
CSF1_1_sha256_2048_65537_v3_usr --id ec705018e9bf8ad60096e13cb2f0fbad
```

Certificate

```
$ p11tool --provider /home/nxf45729/SecurityServerEvaluation-  
V4.20.0.4/Software/Linux/x86-64/Crypto_APIs/PKCS11_R2/lib/libcs_pkcs11_R2.so  
"pkcs11:model=CryptoServer;manufacturer=Utlimaco%20IS%20GmbH;serial=UTIMACO%20  
CS000000;token=CryptoServer%20PKCS11%20Token" so --login --write --load-  
certificate ../../crts/CSF1_1_sha256_2048_65537_v3_usr.crt.pem --label  
CSF1_1_sha256_2048_65537_v3_usr --id ec705018e9bf8ad60096e13cb2f0fbad
```

SoftHSM2

Private Key

```
$ p11tool --provider /usr/lib/softhsm/libsofthsm2.so --login --write  
"<token-url>" --load-privkey  
../../keys/CSF1_1_sha256_2048_65537_v3_usr_key.pem --label  
CSF1_1_sha256_2048_65537_v3_usr --id ec705018e9bf8ad60096e13cb2f0fbad
```

Certificate

```
$ p11tool --provider /usr/lib/softhsm/libsofthsm2.so --login --write  
"<token-url>" --load-certificate  
../../crts/CSF1_1_sha256_2048_65537_v3_usr.crt.pem --label  
CSF1_1_sha256_2048_65537_v3_usr --id ec705018e9bf8ad60096e13cb2f0fbad
```

- 2) Push IMG certificate & key

Utlimaco HSM Simulator

Private key

```
$ p11tool --provider /home/nxf45729/SecurityServerEvaluation-  
V4.20.0.4/Software/Linux/x86-64/Crypto_APIs/PKCS11_R2/lib/libcs_pkcs11_R2.so  
"pkcs11:model=CryptoServer;manufacturer=Utlimaco%20IS%20GmbH;serial=UTIMACO%20  
CS000000;token=CryptoServer%20PKCS11%20Token" so --login --write --load-  
privkey ../../keys/IMG1_1_sha256_2048_65537_v3_usr_key.pem --label  
IMG1_1_sha256_2048_65537_v3_usr --id a0c8cac03985fb6dced29c97dc83aef7
```

Certificate

```
$ p11tool --provider /home/nxf45729/SecurityServerEvaluation-  
V4.20.0.4/Software/Linux/x86-64/Crypto_APIs/PKCS11_R2/lib/libcs_pkcs11_R2.so  
"pkcs11:model=CryptoServer;manufacturer=Utlimaco%20IS%20GmbH;serial=UTIMACO%20
```

```
CS000000;token=CryptoServer%20PKCS11%20Token" so --login --write --load-  
certificate ../../crts/IMG1_1_sha256_2048_65537_v3_usr_cert.pem --label  
IMG1_1_sha256_2048_65537_v3_usr --id a0c8cac03985fb6dced29c97dc83aef7
```

SoftHSM2

```
$ p11tool --provider /usr/lib/softhsm/libsofthsm2.so --login --write  
"<token-url>" --load-privkey  
../../keys/IMG1_1_sha256_2048_65537_v3_usr_key.pem --label  
IMG1_1_sha256_2048_65537_v3_usr --id a0c8cac03985fb6dced29c97dc83aef7
```

```
$ p11tool --provider /usr/lib/softhsm/libsofthsm2.so --login --write  
"<token-url>" --load-certificate  
../../crts/IMG1_1_sha256_2048_65537_v3_usr_cert.pem --label  
IMG1_1_sha256_2048_65537_v3_usr --id a0c8cac03985fb6dced29c97dc83aef7
```

AHAB

For AHAB you should extract the EC public key from the private key and push it to HSM with same ID/Label as private key.

1) Push Private key

```
$ p11tool --provider /home/nxf45729/SecurityServerEvaluation-  
V4.20.0.4/Software/Linux/x86-64/Crypto_APIs/PKCS11_R2/lib/libcs_pkcs11_R2.so  
--login --write "<token-url>" --load-privkey  
../keys/SRK1_sha384_secp384r1_v3_ca_key.pem --label  
SRK1_sha384_secp384r1_v3_ca_key --id b0c8cac03985fb6dced29c97dc83aef7
```

2) Push certificate

```
$ p11tool --provider /home/nxf45729/SecurityServerEvaluation-  
V4.20.0.4/Software/Linux/x86-64/Crypto_APIs/PKCS11_R2/lib/libcs_pkcs11_R2.so  
--login --write "<token-url>" --load-certificate  
./SRK1_sha384_secp384r1_v3_ca_cert.pem --label SRK1_sha384_secp384r1_v3_ca_cert  
--id b0c8cac03985fb6dced29c97dc83aef7
```

3) Push Public key

```
$ openssl ec -in relase/keys/SRK1_sha384_secp384r1_v3_ca_key.pem -pubout -out  
SRK1_sha384_secp384r1_v3_ca_pubkey.pem
```

```
$ p11tool --provider /home/nxf45729/SecurityServerEvaluation-  
V4.20.0.4/Software/Linux/x86-64/Crypto_APIs/PKCS11_R2/lib/libcs_pkcs11_R2.so  
--login --write "<token-url>" --load-pubkey  
SRK1_sha384_secp384r1_v3_ca_pubkey.pem --label  
SRK1_sha384_secp384r1_v3_ca_pubkey --id b0c8cac03985fb6dced29c97dc83aef7
```

3.4.5 Verification

Verify that all cryptographic materials were written correctly to token by running.

```
$ p11tool --provider "<pkcs11-module>" "<token-url>" --list-all --login
```

Enter PIN when prompts

3.5 Pull certificates from HSM

3.5.1 Install p11tool

To perform interact with HSM you can use p11tool.

```
$ apt-get install gnutls-bin
```

3.5.1 Find Token URL

Find the Token URL to interact with the token.

```
$ p11tool --provider /usr/lib/softhsm/libsofthsm2.so --list-tokens
```

```
Token 0:
  URL:
pkcs11:model=SoftHSM%20v2;manufacturer=SoftHSM%20project;serial=9c1aeb00e05a348b;token=CST-HSM
  Label: CST-HSM
  Type: Generic token
  Manufacturer: SoftHSM project
  Model: SoftHSM v2
  Serial: 9c1aeb00e05a348b
  Module: (null)
```

In this case Token URL is

```
pkcs11:model=SoftHSM%20v2;manufacturer=SoftHSM%20project;serial=9c1aeb00e05a348b;token=CST-HSM
```

3.4.3 Pull Certificates

HABv4

Pull CSF & IMG certificate

List all certificates on HSM

```
$ p11tool --provider /usr/lib/softhsm/libsofthsm2.so "<token-url>" --list-all-certs
```

Pull CSF certificate from HSM

```
$ p11tool --provider /usr/lib/softhsm/libsofthsm2.so --export "<cert-url>" --outfile CSF1_1_sha256_2048_65537_v3_ca.crt.pem
```

Pull IMG certificate from HSM

```
$ p11tool --provider /usr/lib/softhsm/libsofthsm2.so --export "<cert-url>" --outfile IMG1_1_sha256_2048_65537_v3_ca.crt.pem
```

Pull SRK certificate

```
$ p11tool --provider /usr/lib/softhsm/libsofthsm2.so --export "<cert-url>" --outfile SRK1_sha384_secp384r1_v3_ca.crt.pem
```

3.6 Create HSM configuration file

Create a **hsm.cfg** file in the same folder as CST. The configuration file specifies the following parameters.

- **hsm.module** contains the path to vendor's PKCS#11 implementation library
- **hsm.pin** specifies the User PIN
- **hsm.slot** specifies the SLOT ID
- **hsm.objects** is a lookup table which bind a cryptographic material on the file system to its Object ID on the HSM. This is needed since the current frontend implementation loads and checks certificates from the file system and then provide as argument the certificate path to the backend. The backend can see a path only. To be load the required certificate and its private key from the HSM, the backend uses this lookup.

```
$ nano hsm.cfg
```

HABv4

```
# hsm stuff
hsm:
{
  module = "/home/nxf45729/SecurityServerEvaluation-
V4.20.0.4/Software/Linux/x86-
64/Crypto_APIs/PKCS11_R2/lib/libcs_pkcs11_R2.so";
  pin = "123456";
  slot = 0;
  objects = (
    { file = "./CSF1_1_sha256_2048_65537_v3_usr_cert.pem";
      id = "ec705018e9bf8ad60096e13cb2f0fbad";
    },
    { file = "./IMG1_1_sha256_2048_65537_v3_usr_cert.pem";
      id = "a0c8cac03985fb6dced29c97dc83aef7";
    }
  );
};
```

For SRK tool you may need to pull all SRK certificates.

AHAB

```
# hsm stuff
hsm:
{
  module = "/home/nxf45729/SecurityServerEvaluation-
V4.20.0.4/Software/Linux/x86-
64/Crypto_APIs/PKCS11_R2/lib/libcs_pkcs11_R2.so";
  pin = "12345678";
  slot = 0;
  objects = (
    { file = "./SRK1_sha384_secp384r1_v3_ca_cert.pem";
      id = "b0c8cac03985fb6dced29c97dc83aef7";
    }
  );
};
```

D. RUN

Generate the CSF binary signature

```
$ ./cst -i u-boot.csf -o u-boot.csf.bin  
CSF Processed successfully and signed data available in u-boot.csf.bin
```